




R&M Materials Handling, Inc.
SPACEMASTER Hoist & Crane Products
 4501 Gateway Boulevard
 Springfield, Ohio 45502
 ☎ : (937) 328-5100
 FAX: (937) 325-5319

STOPMASTER

SECTION
STOPMASTER

PAGE
 1-1

DATE
 AUGUST 1980



SERVICE NOTE:
 Suffix portions of
 model no. identify
 current sensors.

MODEL	1	2	3	4	5	6	7
SM-1111-0-0							
SM-1113-0-0							
SM-1121-0-0							
SM-1123-0-0							
SM-1212-0-0							
SM-1222-0-0							
SM-2111-0-0							
SM-2113-0-0							
SM-2121-0-0							
SM-2123-0-0							
SM-2212-0-0							
SM-2222-0-0							

ITEM NUMBER	PART NUMBER	DESCRIPTION	QUANTITY						
			1	2	3	4	5	6	7
8413	24-05977-001	circuit board	1	1	1	1	1		
	24-05978-001	circuit board			1	1	1	1	1
8414 *	22-11487-001	relay							
8415 8416 (two spd only)	23-07672-011	current sensor						1	
	23-07672-008	current sensor						1	1
	23-07672-009	current sensor						1	
	23-07672-002	current sensor						1	1
	23-07672-010	current sensor						1	1
	23-07672-005	current sensor						1	1
	23-07672-007	current sensor						1	1
8417	22-11484-001	terminal strip	2	2	2	2	2	2	
8418	22-10695-001	auxiliary relay	2	2	2	2	2	2	
(not shown)	22-11531-001	screwdriver adjusting tool	1	1	1	1	1	1	1

SECTION

PAGE

DATE



R&M Materials Handling, Inc.
SPACEMASTER Hoist & Crane Products
4501 Gateway Boulevard
Springfield, Ohio 45502
☎ : (937) 328-5100
FAX: (937) 325-5319